


DESPIECE TR-412



Nº	CÓDIGO	DENOMINACIÓN
1	05BETN00015	Boquilla M-12
2	05BETN00002	Contratuerca
3	05TR0412003	Tuerca porta boquilla
4	05TR0412004	Anillo goma
5	05TR0412005	Porta boquilla
6	05BETN00019	Macho M-12
7	05TR0412007	Cuerpo remachadora
8	05TR0412008	Rueda giro macho
9	05TR0412009	Empuñadura negra
10	05TR0412010	Interruptor cambio giro
11	05BETN00012	Boquilla M-5
12	05BETN00013	Boquilla M-6
13	05BETN00014	Boquilla M-8
14	05BETN00001	Boquilla M-10
15	05BETN00016	Macho M-5
16	05BETN00017	Macho M-6
17	05BETN00018	Macho M-8
18	05BETN00003	Macho M-10
19	05BETN00034	Boquilla Espárrago M-5
20	05BETN00035	Boquilla Espárrago M-6
21	05BETN00036	Boquilla Espárrago M-8
22	05BETN00020	Boquilla m-4 BET-N
23	05BETN00021	Macho m-4 BET-N