


DESPIECE BNT-N



Nº	CÓDIGO	DENOMINACIÓN
1	05BNTN00001	PORTA BOQUILLA
2	05BNTN00002	PORTA MACHO
3	05BNTN00003	CONECTOR FIJACION MACHO
4	05BNTN00004	VARILLA
5	05BNTN00005	PORTA VARILLA
6	05BNTN00006	MUELLE PORTA VARILLA
7	05BNTN00007	TUERCA DE BLOQUEO
8	05BNTN00008	GRUPILLA 2 UNDS
9	05BNTN00009	ARANDELA 3 UNDS
10	05BNTN00010	JUNTA TORICA 3 UNDS CAMISA TRACCION
11	05BNTN00011	PIVOTE DE MOVIMIENTO
12	05BNTN00012	EMPAQUETADURA
13	05BNTN00013	TORNILLO PURGADO M5
14	05BNTN00014	JUNTA TORNILLO PURGADO
15	05BNTN00015	ANILLO DE AJUSTE
16	05BNTN00016	EMPAQUETADURA
17	05BNTN00017	JUNTA TORICA EJE TRACCION
18	05BNTN00018	PISTON HIDRAULICO
19	05BNTN00019	MUELLE
20	05BNTN00020	TORNILLO 2 UNDS
21	05BNTN00021	TOPE CARRERA
22	05BNTN00022	TORNILLO M4 4 UNDS
23	05BNTN00023	VARILLA DE EMPUJE
24	05BNTN00024	BOLA CIERRE
25	05BNTN00025	JUNTA TORICA (KIT DISTRIBUIDOR)
26	05BNTN00026	DISTRIBUIDOR TRASERO (KIT DISTRIBUIDOR)
27	05BNTN00027	GRUPILLA (KIT DISTRIBUIDOR)
28	05BNTN00028	MUELLE (KIT DISTRIBUIDOR)
29	05BNTN00029	TORNILLO M4 2 UNDS (KIT DISTRIBUIDOR)
30	05BNTN00030	SILENCIADOR
31	05BNTN00031	CARCASA TRASERA
32	05BNTN00032	JUNTA TORICA 3 UNDS (KIT DISTRIBUIDOR)
33	05BNTN00033	PISTÓN (KIT DISTRIBUIDOR)
34	05BNTN00034	JUNTA TORICA 4 UNDS (KIT DISTRIBUIDOR)
35	05BNTN00035	JUNTA TORICA 3 UNDS (KIT DISTRIBUIDOR V.P)
36	05BNTN00036	TUBOS DE SUMINISTRO DE AIRE 2 UNDS
37	05BNTN00037	TORNILLO + JUNTA ACEITE
38	05BNTN00038	EMPUÑADURA PLASTICO
39	05BNTN00039	JUNTA TAPON EMPUÑADURA
40	05BNTN00040	ARANDELA ENTRADA AIRE 2 UNDS
41	05BNTN00041	CONJUNTO ENTRADA DE AIRE
42	05BNTN00042	VARILLA (KIT VALVULA PRESION)
43	05BNTN00043	EMPAQUETADURA (KIT VALVULA PRESION)
44	05BNTN00044	PISTÓN (KIT VALVULA PRESION)
45	05BNTN00045	CARCASA DELANTERA (KIT VALVULA PRESION)
46	05BNTN00046	JUNTA TORICA 3 UNDS (KIT VALVULA PRESION)
47	05BNTN00047	CILINDRO (KIT VALVULA PRESION)
48	05BNTN00048	CARCASA TRASERA (KIT VALVULA PRESION)

Nº	CÓDIGO	DENOMINACIÓN
49	05BNTN00049	PROTECCION (KIT VALVULA PRESION)
50	05BNTN00050	REGULADOR PRESION (KIT VALVULA PRESION)
51	05BNTN00051	MUELLE (KIT VALVULA PRESION)
52	05BNTN00052	ANILLO (KIT VALVULA PRESION)
53	05BNTN00053	RETENEDOR DE MUELLE (KIT VALVULA PRESION)
54	05BNTN00054	JUNTA TORICA 2 UNDS (KIT VALVULA VASO AIRE)
55	05BNTN00055	JUNTA TORICA 2 UNDS (KIT VALVULA PRESION)
56	05BNTN00056	MUELLE (KIT VALVULA PRESION)
57	05BNTN00057	JUNTA TORICA 2 UNDS
58	05BNTN00058	MUELLE
59	05BNTN00059	JUNTA TORICA EMBOLO VASO
60	05BNTN00060	VASO NEUMÁTICO
61	05BNTN00061	TUBO DE SUMINISTRO DE AIRE
62	05BNTN00062	JUNTA TORICA
63	05BNTN00063	BASE GOMA
64	05BNTN00064	JUNTA TORICA 4 UNDS
65	05BNTN00065	TAPON VASO
66	05BNTN00066	TUERCA 2 UNDS
67	05BNTN00067	ARANDELA 4 UNDS
68	05BNTN00068	TAPA VASO NEUMATICO
69	05BNTN00069	TIRANTE ROSCADO 2 UNDS
70	05BNTN00070	PISTON NEUMATICO
71	05BNTN00071	JUNTA TORICA TAPON EMPUÑADURA
72	05BNTN00072	EMPAQUETADURA
73	05BNTN00073	GUÍA EJE PISTON
74	05BNTN00074	JUNTA TORICA (KIT VALVULA GATILLO)
75	05BNTN00075	CAMISA BARRA GATILLO (KIT VALVULA GATILLO)
76	05BNTN00076	JUNTA TORICA 2 UNDS TIRANTE ROSCADO
77	05BNTN00077	JUNTA TORICA (KIT VALVULA GATILLO)
78	05BNTN00078	BARRA DEL GATILLO (KIT VALVULA GATILLO)
79	05BNTN00079	JUNTA TORICA (KIT VALVULA GATILLO)
80	05BNTN00080	PASDOR DEL RODILLO (KIT GATILLO)
81	05BNTN00081	RODILLO (KIT GATILLO)
82	05BNTN00082	CUNA DE EMPUJE (KIT GATILLO)
83	05BNTN00083	GATILLO (KIT GATILLO)
84	05BNTN00084	PASADOR DE PIVOTE (KIT GATILLO)
85	05BNTN00085	PASADOR ROSCADO
86	05BNTN00086	DEFLECTOR
87	05BNTN00087	SILENCIADOR
88	05BNTN00088	MUELLE (KIT VALVULA VASO AIRE)
89	05BNTN00089	PISTON DE VALVULA (KIT VALVULA VASO AIRE)
90	05BNTN00090	MUELLE (KIT VALVULA VASO AIRE)
91	05BNTN00091	TUERCA DEL ADAPTADOR
92	05BNTN00092	JUNTA TORICA (KIT VALVULA VASO AIRE)
93	05BNTN00093	JUNTA TORICA (KIT VALVULA VASO AIRE)
94	05BNTN00094	TORNILLO
95	05BNTN00095	EJE PISTON NEUMATICO
96	05BNTN00096	PRISIONERO VARILLA

05BNTN00172	KIT MOTOR
05BNTN00173	KIT DISTRIBUIDOR
05BNTN00174	KIT VALVULA PRESION
05BNTN00175	KIT VALVULA VASO AIRE
05BNTN00176	KIT VALVULA GATILLO
05BNTN00177	KIT GATILLO
05BNTN00178	KIT LLAVERES

OPCIONAL

KIT TUERCA

M-3	05BNTN00157
M-4	05BNTN00158
M-5	05BNTN00159
M-6	05BNTN00160
M-8	05BNTN00161
M-10	05BNTN00162

KIT TUERCA UNC

UNC 6-32	05BNTN00167
UNC 8-32	05BNTN00168
UNC 10-32	05BNTN00184
UNC 1/4-20	05BNTN00169
UNC 5/16-18	05BNTN00170
UNC 3/8-16	05BNTN00171

KIT ESPÁRRAGO REMACHABLE

M-4	05BNTN00163
M-5	05BNTN00164
M-6	05BNTN00165
M-8	05BNTN00166