







N°	REFERENCE	DESCRIPTION
1	05PT0000023	NOSEPIECE HOLDER
2	05BM0001002	JAWS
3	05BT2000005	PUSHER -3.20
3	05BT2000006	PUSHER +3.20
4	05PT0000042	JAWS HOLDERS
5	05BT2000007	JAWS SPRING
6	05PT0000053	JAWS HOLDERS WASHER
7	05PT0000077	JAWS HOLDERS SEAL
8	05PT0000032	JAWS HOLDERS CONNECTOR
9	05PT0000031	JAWS HOLDERS LOCK NUT
10	05PT0000048	DRIVE AXLE INSERT PT8L
10	05PT0000049	DRIVE AXLE INSERT PT20
11	05PT0000014	FRONT DRIVE AXLE
12	05PT0000076	NOZZLE HOLDER SEAL
13	05PT0000075	BODY / AXLE SEAL
14	05PT0000050	HANGING RING
15	05PT0000074	BODY / AXLE PACKING
16	05PT0000073	AXLE PACKING
17	05PT0000072	AXLE / BODY SEAL
18	05PT0000015	REAR DRIVE AXLE
19	05PT0000071	PLUG / BODY SEAL
20	05PT0000092	PLUG / DRIVE AXLE SEAL
21	05PT0000024	BODY AXLE PLUG
22	05PT0000028	BODY PLUG COVER
23	05PT0000057	EJECTOR WASHER
24	05PT0000058	PLUG/STEM COLLECTOR SEAL
25	05PT0000030	PLUG COLLECTOR
26	05PT0000036	STEM EJECTOR
27	05PT0000029	STEM COLLECTOR
28	05PT0000026	TRIGGER SHAFT PIN
29	05PT0000027	SUCTION CUT-OFF SHAFT
30	05PT0000051	OIL SCREW
31	05PT0000025	TRIGGER
32	05PT0000045	DRIVE SHAFT
33	05PT0000004	MAIN BODY
34	05PT0000070	BODY / GLASS GASKET
35	05PT0000079	SUPPORT RING
36	05PT0000078	BODY / PLUNGER SHAFT GASKET
37	05PT0000006	BODY/COVER UNION NUT
38	05PT0000056	POSITIONER
39	05PT0000054	SILENCER
40	05PT0000001	CUP LID
41	05PT0000033	BRASS TUBE
42	05PT0000020	PISTON SHAFT
43	05PT0000044	PISTON RUBBER STOP
44	05PT0000091	PISTON-TUBE SEAL
45	05PT0000018	PISTON
46	05PT0000082	PISTON SEAL
47	05PT0000038	PISTON LOWER STOP
48	05PT0000084	COVER SEAL
49	05PT0000043	PISTON-PISTON SCREW
50	05PT0000016	CUP CLOSING LID
51	05PT0000046	PROTECTION RUBBER
53	05PT0000090	SUCTION SEAL SEAL
54	05PT0000052	AIR CUT-OFF SHAFT GROUP
55	05PT0000012	AIR INLET PLUG
56	05PT0000088	SEAL WASHER SEAL
57	05PT0000040	VALVE SEAL WASHER
58	05PT0000041	O-RING
59	05PT0000086	VALVE SEAL
60	05PT0000011	ACTUATOR VALVE
61	05PT0000087	VALVE SEAL
62	05PT0000089	VALVE/SAFETY PLUG SEAL
63	05PT0000007	SAFETY VALVE ASSEMBLY
	05BT2000041	KEY 12-17
	05BM0000099	FITTING
	05BT2000051	NOSEPIECE 3.2 B
	05BT2000052	NOSEPIECE 4.0 C
	05BT2000053	NOSEPIECE 4.8 D
	05BT2000054	NOSEPIECE 6.0 E
	05BT2000055	NOSEPIECE 6.4 F

OPTIONAL

REFERENCE	DESCRIPTION
05PT0000096	LONG MANDREL COLLECTION TUBE
05BT2000104	KIT 2.4
05BT2000063	NOSEPIECE 4.8 STRUCTURAL G
05BT2000094	NOSEPIECE 4.8 MULTILOCK W

OUTIL CHANGE KIT 05PT0000101 INCLUDES:

05PT0000093	OIL FILLING TOOL
05PT0000094	BRAKE AXLE SCREW
05PT0000095	SYRINGE
05BNT000420	OIL CAN